

# smiggle skin

## **Device List**

as of 29-06-2010



<b>Contents</b>	<b>Page</b>
<b>Apple</b>	<b>3</b>
<b>BlackBerry</b>	<b>3</b>
<b>Dopod</b>	<b>3</b>
<b>HTC</b>	<b>4</b>
<b>i-Mate</b>	<b>4</b>
<b>LG</b>	<b>4/5</b>
<b>Motorola</b>	<b>5</b>
<b>Nintendo</b>	<b>6</b>
<b>Nokia</b>	<b>6/7/8</b>
<b>O2</b>	<b>8</b>
<b>Okta</b>	<b>8</b>
<b>Palm</b>	<b>9</b>
<b>Panasonic</b>	<b>9</b>
<b>Porsche Design</b>	<b>9</b>
<b>Sagem</b>	<b>9</b>
<b>Samsung</b>	<b>9/10/11</b>
<b>Sanyo</b>	<b>11</b>
<b>Sony Ericsson</b>	<b>11/12</b>
<b>Telstra</b>	<b>12</b>
<b>Three</b>	<b>12</b>
<b>Vodafone</b>	<b>13</b>

## Apple

---

iPhone 3G  
iPod Classic Gen 5  
iPod Gen 4  
iPod Mini  
iPod Nano Gen 2  
iPod Nano Gen 3  
iPod Nano Gen 4  
iPod Nano Gen 5  
iPod Original Nano  
iPod Shuffle Gen 1  
iPod Shuffle Gen 2  
iPod Shuffle Gen 3  
iPod Touch Gen 1  
iPod Touch Gen 2

## BlackBerry

---

7100x  
7130G  
8100 Pearl  
8110 Pearl  
8300  
8330 Curve  
8700g  
8707g  
8800  
8900 Curve  
9000 Bold  
9500 Storm  
9700

## Dopod

---

838 Pro  
D810

## HTC

---

Desire  
Dream  
Magic  
Snap  
Tilt 2  
Titan  
Touch  
Touch Diamond  
Touch Dual  
Touch HD  
Touch HD2  
Touch Pro  
TyTN 2

## i-Mate

---

8502  
9502  
JasJam  
SP5

## LG

---

550  
Choc Slide  
Cookie  
GB110  
GB220  
GM730  
GS108  
KC910  
KE770  
KE970 Shine  
KF310  
KF390  
KF510  
KF600  
KF700  
KF750  
KG220  
KG245  
KG290

## LG Continued

**Smiggle Skin - Device List as of 20-10-2009**

**Please note:** The list has been compiled alphabetically and numerically by Manufacture then model.



KG375  
KG800 Chocolate  
KM900F  
KP105  
KP202  
KP230  
KP500 Cookie  
KS360  
KU990 Viewty  
Prada  
Prada KF900  
Renoir  
TU500  
TU575  
TU720 Shine Next G  
U300  
U310  
U400  
U830  
Viewty Smart

## Motorola

---

3Vi  
C261  
E8  
EM325  
HipTop 2  
K1  
L2  
L6  
L7  
Maxx V6  
Motofone F3  
Motokrzzr K3  
PEBL U6  
Q9  
RAZR2 V9  
Rokr E1  
U9  
V3  
V3x  
V3xx  
V8  
V9  
VE538  
W156  
W218  
W375  
Z6

## Nintendo

---

DS Lite  
DSi

## Nokia

---

1110i  
1112  
1202  
1208  
1209  
1325  
1600  
1650  
1680 Classic  
2112  
2125  
2300  
2310  
2323  
2330  
2600  
2600 Classic  
2600 Slide  
2610  
2626  
2630  
2680 Slide  
2700  
2720  
2730  
2760  
2865  
3109  
3110  
3120  
3120 Classic  
3230  
3250  
3500 Classic  
3600 Slide  
5000  
5030  
5070  
5130  
5200  
5233

**Nokia Continued.**



5235  
5300  
5310  
5500  
5610  
5700  
5800 XpressMusic  
6020  
6021  
6030  
6060  
6070  
6080  
6085  
6101  
6103  
6110  
6111  
6120  
6124  
6125  
6131  
6151  
6210 Navigator  
6220  
6230i  
6233  
6234  
6267  
6275  
6280  
6288  
6300  
6310  
6500 Classic  
6500 Slide  
6600 Fold  
6600 Slide  
6610  
6630  
6670  
6680  
6700  
6700 Slide  
6710  
6720  
6760  
7100 Supernova  
7210 Supernova  
7230  
7360  
7370  
7380

**Nokia Continued.**

**Smiggle Skin - Device List as of 20-10-2009**

**Please note:** The list has been compiled alphabetically and numerically by Manufacture then model.

7390  
8800  
8800 Arte  
8800 Arte Sapphire  
8800 Sirocco  
E51  
E52  
E61  
E61i  
E63  
E65  
E66  
E71  
E72  
E75  
N7 Mini  
N70  
N73  
N76  
N78  
N80  
N81  
N82  
N85  
N86  
N90  
N91  
N91 8GB  
N93  
N93i  
N95  
N95 Gen 1  
N95 8GB  
N95-2 8GB  
N95-3 NAM  
N96  
N97

## O2

---

XDA Neo  
XDA Flame

## Okta

---

Boss  
Mondo  
Touch

---

## **Palm**

---

Centro  
Treo 750  
Treo 500V  
Treo Pro

## **Panasonic**

---

VS2

## **Porsche Design**

---

Porsche Design P9521

## **Sagem**

---

C5-3  
MY212X  
MY220X  
MY411CV  
MY411X  
MY501C

## **Samsung**

---

A130  
A411  
A412  
A551  
A561  
A711  
A801  
A811  
A900  
Black Jack  
**Samsung Continued.**

B100  
B3310  
B520v  
C-3110  
C170  
C300  
C520  
C5220  
D520  
D600  
E1100T  
E210  
E250  
E2510  
E370  
E590  
E740  
E900  
F330  
F480 Ice Silver  
F480T  
G600  
G800  
G810  
GT-B2700  
GT-B3410  
GT-C3050  
HD Icon  
i200  
i325 Global  
i450  
i560  
i600  
i616  
i617T  
i7500  
i780  
i8510  
i8510 INNOV8  
i8910  
i900 OMNIA  
Impact  
J700  
J750  
Jet Icon  
L760  
L810  
M300  
M510  
M610  
Omnia icon  
Omina Pro  
Preston

**Samsung Continued.**

S3653  
S6700T  
S7330  
S7350  
S8300  
SPH M300  
U100  
U300  
U700  
U900  
W531  
Widescreen  
X530  
X830  
Z140  
Z230  
Z400  
Z510

## Sanyo

---

3800  
6650  
7050  
8500  
S1

## Sony Ericsson

---

C510  
C702  
C902  
C903  
C905  
F305  
G502  
G900  
K530i  
K550i  
K610i  
K660i  
K750i  
K770i  
K800i  
K810i  
K850i  
M600i

**Sony Ericsson Continued.**

S500i  
T250i  
T303  
T650i  
T707  
W200i  
W300i  
W350  
W380  
W395  
**W508**  
W580i  
W595  
W610i  
W660i  
W705  
W760  
W800i  
W810  
W850i  
W880i  
W890i  
W902  
W910i  
W980  
W995  
W800i  
XPERIA X1  
XPERIA X10  
Z310i  
Z530i  
Z550i  
Z610i

## Telstra

---

7 Series Modem  
21 Series Modem  
150  
EZ Touch Discovery  
EZ Touch Discovery 2  
F851  
T6  
T100  
ZTE T106  
ZTE156  
ZTE F158  
ZTE 165i  
ZTE256  
ZTE Country Phone

## Three

---

**Smiggle Skin - Device List as of 20-10-2009**

**Please note:** The list has been compiled alphabetically and numerically by Manufacture then model.

E160 USB Modem  
E180 USB Modem  
INQ1  
Skype Phone S1

## Vodafone

---

226  
541  
Modem